



GUARANTEE

IMPORTANT!
To assure product SAFETY and RELIABILITY, repairs, maintenance and adjustment should be performed by BLACK & DECKER Service Centers or other qualified service organizations, always using BLACK & DECKER replacement parts.

OWNER'S MANUAL

FACTORY SALES & SERVICE CENTERS



Area	Telephone Code No.	Address	Code No.
ALABAMA: Birmingham 35233, 1717 Third Ave., South .205	324-6691	NEBRASKA: Omaha 68102, 2218 Leavenworth Street	402
ARKANSAS: Little Rock, 2201, 519 McDaniel Rd.	602 AL-8-1332	NEW MEXICO: Albuquerque 87104, 4700 Lomas Blvd. N.E. 501	205 HU-1076
CALIFORNIA: Anaheim 93802, 1235 So. Euclid Ave.	714	New York: Buffalo 4209, 1894 E. Tremont Avenue (Bronx)	216 SY-2220
Los Angeles 10503, 1107 E. 11th St., 11th St. Highway	413	New York: Buffalo 4209, 1894 E. Tremont Ave. (Bronx)	212 SY-2220
Santa Diego 22105, 3811 El Cajon Blvd.	714	New York: Buffalo 4209, 1894 E. Tremont Ave. (Bronx)	212 DF-1050
San Diego 22105, 3811 El Cajon Blvd.	408	New York: Buffalo 4209, 1894 E. Tremont Ave. (Bronx)	212 DF-1050
San Jose 95020, 2231 The Alameda	241	Rochester 14620, 476 Clinton Ave. S.	716 454-3814
San Francisco 14500, 1450 18th Street	215	Syracuse 3224, 2140 Erie Blvd. E.	716 456-0386
Colorado: Denver 80204, 672 Kalmarath St.	303	NORTH CAROLINA: Charlotte 28206, 1710 N. Graham St.	704 FR-5-3721
CONNECTICUT: Hartford 06114, 131 Meadow Street	203	Tulsa 73105, 108 W. 43rd Street (Highway 301, S.)	919 222-1381
DISTRICT OF COLUMBIA: Washington 20010, 4501 Baltimore Ave.	301	PAYMENT: Portland 97209, 108 W. 43rd Street (Highway 301, S.)	918 622-5666
MARYLAND: 32006, 5224 Annapolis Road	779-3898	OREGON: Portland 97209, 1640 N. Johnson Street	503 CA-8-6631
Florida: Orlando 42206, 5224 Annapolis Road	504	HARRISBURG: Harrisburg 17112, 6070 Allentown Blvd.	513 421-2275
Orlando 32806, 340 So. Orange Ave.	423-6651	CINCINNATI: Cincinnati 45203, 1825 Western Ave.	216 OL-14243
Tampa 33609, 3401 W. Kennedy Blvd.	813	CLEVELAND: 44113, 3901 Detroit Ave.	614 233-0461
Georgia: Atlanta 30313, 311 Techwood Drive, NW	404	Columbus 43202, 3975 E. Livingston Ave.	513 253-5821
HAWAII: Honolulu 96833, 675 Alihi Street	808	Dayton 45205, 617 W. Waterford Street	412 G-5-6771
ILLINOIS: Chicago 60645, 1900 N. Western Ave.	312	DETROIT: Detroit 13066, 625 W. Central Ave.	419 476-2771
Chicago 60643, 2205 N. Western Ave.	312	INDIANAPOLIS: Indianapolis 46206, 1100 W. Market St.	405 CE-2-3721
INDIANA: Evansville 47708, 309 First Ave.	812	KNOXVILLE: Knoxville 37917, 1123 North Central St.	615 546-4269
Indianapolis 46222, 561 16th St.	305	MILWAUKEE: Milwaukee 53205, 605 E. Kenosha Rd.	591 253-1061
KANSAS: Wichita 67214, 263 N. Massachusetts Street	315	MINNEAPOLIS: Minneapolis 55427, 205 E. Franklin Ave. S.	806 253-1061
KENTUCKY: Louisville 40209, 4407 Park Blvd.	502	TEXAS: Amarillo 79106, 306 West 6th Ave.	806 253-1061
LOUISIANA: New Orleans 70002, 3310 N. Causeway Blvd.	504	DALLAS: Dallas 75207, 1808 N. Industrial Blvd.	214 RI-1401
MARYLAND: Baltimore 21211, 203 West 28th Street	301	FORT WORTH: Fort Worth 76103, 180 Bonita Street	817 338-9175
Baltimore 21205, 472 Erdman Ave.	301	HOUSTON: Houston 71038, 105 Sampson Street	513 222-9227
Baltimore 21205, 472 Erdman Ave.	301	MEMPHIS: Memphis 38120, 100 2nd Street	513 244-4621
MASSACHUSETTS: Boston 02155, 12 Market St. (Beacon)	301	PHILADELPHIA: Philadelphia 19104, 1541 S. Second West Street	801 HU-57056
BOSTON 02155, 12 Market St. (Beacon)	617	PORTLAND: Salt Lake City 8441115, 1541 S. Second West Street	703 533-1147
IDAHO: Boise, 18133, 18133 W. McNeel Rd.	313	RICHMOND: Richmond 23222, 1424 Chamberlayne Ave.	703 649-4521
IDAHO: Boise, 18133, 18133 W. McNeel Rd.	534-8880	SEATTLE: Seattle 98119, 701 Third Ave. N.	206 AT-2-6432
IDAHO: Boise, 18133, 18133 W. McNeel Rd.	616	SPokane 99207, 3550 North Market Street	599 HA-1-1493
MINNESOTA: Minneapolis 11360, East Seven Mile Road	612	WEST VIRGINIA: Charleston 25112, 1688 Sixth Ave.	599 HA-1-1493
MINNESOTA: Minneapolis 11360, East Seven Mile Road	534-5283	WISCONSIN: Milwaukee 53213, 6301 Blue Mound Road	414 GR-6-7830
MISSOURI: Kansas City 64108, 2705 McGee Trafficway	816		
MISSOURI: Kansas City 64108, 2705 McGee Trafficway	816		
ST. LOUIS: 63110, 615 S. Ve deventer Ave.	301		
ST. LOUIS: 63110, 615 S. Ve deventer Ave.	JE-3-2210		

Your new Black & Decker Vacuum Cleaner is an outstanding value, combining quality construction, excellent performance and versatility with an economical price. It is a very good choice for cleaning up DRY materials in all areas of the garage or service station.

For personal safety and for proper operation of the Vacuum Cleaner, please read the instructions and safety rules carefully. Don't forget to send in your guarantee registration card. THANK YOU for buying BLACK & DECKER!


THE BLACK & DECKER MFG. CO., TOWSON, MD. 21204, U.S.A.

(B11-PS) Printed in U.S.A.

Form No. 97246

CAT. NO. 6600 5-GAL. VACUUM CLEANER

CAT. NO. 6605 10-GAL. VACUUM CLEANER



Black & Decker VACUUM CLEANERS



P.T.I. SAFETY RULES FOR POWER TOOLS

- KNOW YOUR POWER TOOL** — Read owner's manual carefully. Learn its applications and limitations as well as the specific potential hazards peculiar to this tool.
- GROUND ALL TOOLS — UNLESS DOUBLE-INSULATED.** If tool is equipped with three-prong plug, it should be plugged into a three-hole electrical receptacle. If adapter is used to accommodate two-prong receptacle, the adapter wire must be attached to a known ground. Never remove third prong.
- AVOID DANGEROUS ENVIRONMENT.** Don't use power tool in damp or wet locations. And keep work area well lit.
- STORE IDLE TOOLS.** When not in use, tools should be stored in dry, high or locked-up place — out of reach of children.
- WEAR PROPER APPAREL.** No loose clothing or jewelry to get caught in moving parts. Rubber gloves and footwear are recommended when working outdoors.
- DON'T ABUSE CORD.** Never carry tool by cord or yank it to disconnect from receptacle. Keep cord from heat, oil and sharp edges.
- DON'T OVERREACH.** Keep proper footing and balance at all times.
- DISCONNECT TOOLS.** When not in use, before servicing; when emptying your vacuum cleaner.

DOLLY (Figure 2)





FIG. 1

This Dolly is standard equipment with your Vacuum Cleaner. To attach the Dolly, place the bottom edge of the cleaner (with the inlet opening above the small wheel) under the hooks "J". Center the cleaner between the large wheels and tighten screw "K".

WARNING—Never maneuver the Vacuum Cleaner by pulling the electric cord.

ADDITIONAL SAFETY RULES FOR VACUUM CLEANERS

- Always unplug the cord from the electric outlet before releasing clamps, "E" Figure 1, to remove top of cleaner for emptying.
- If you clean out fireplace ashes, be sure that they are dead out and cold.
- Do not allow sparks from tools such as bench grinders, sanders, etc. to be sucked into the cleaner, unless it has been completely emptied beforehand.
- Do not use the cleaner to pick up wet materials. IT IS INTENDED FOR DRY PICK-UP ONLY!
- Never maneuver the vacuum cleaner by pulling the electric cord.

Black & Decker

VACUUM CLEANERS

GROUNDING


Your Cleaner has a grounding system to protect you from electric shock if some damage should occur to the wiring of the cleaner. This system utilizes an approved 3-conductor power cord and 3-prong grounding type attachment plug, which should be used with the proper grounding type receptacle, in accordance with the National Electric Code, Canadian Electrical Code, and Underwriters' Laboratories specifications.

If your unit requires less than 150 volts it has a plug that looks like Fig. "A". It will fit directly into the proper type of 3-wire grounding receptacle. The unit is then grounded automatically each time it is plugged in.

Shown in Fig. "B" is a special grounding adapter (not allowed in Canada by the Canadian Electrical Code) which is available from your dealer and will permit using a 2-wire receptacle. The green grounding wire extending from the side of the adapter must be connected to a Permanent Ground.

If the unit requires from 150 to 250 volts, it has a plug like Fig. "C". No adapter is available and the plug must be used in the proper 3-wire grounding receptacle.

We recommend that you NEVER disassemble the tool or try to do any rewiring in the electrical system. Any such repairs should be performed only by B&D Service Centers or other qualified service organizations. Should you be determined to make a repair yourself, remember that the green colored wire is the "grounding" wire. Never connect this green wire to a "live" terminal. If you replace the plug on the power cord, be sure to connect the green wire only to the grounding (longest) prong on a 3-prong plug.



EXTENSION CORD


When using the tool at a distance where an extension cord becomes necessary, a 3-conductor, grounding-type extension cord of adequate size must be used for safety, and to prevent loss of power and over-heating. Use the table below to determine A.W.G. Wire size required:

Extension Cord Length in feet 25 50 75 100

A.W.G. Wire size required:

120 Volts 18 16 14 12

Before using tool cord or extension cord, inspect them for loose or exposed wires and damaged insulation. Make any needed repairs or replacement before using your power tool.



USAGE

Your Black & Decker Vacuum Cleaner is a versatile machine, capable of most of the cleaning jobs in cars or buildings. Many different accessories can expand its usage to practically any type of vacuum cleaning. Since this cleaner is intended for dry pick-up only, do not use it in wet areas or for picking up wet materials.

The 5-inch nozzle and 2½" diameter hose (standard equipment with cleaner) are ideal for pick-up of items such as sand, dirt and pebbles. You can increase this cleaning versatility by adding 2½" accessories like the 14" floor nozzle, crevice tool and round brush.

The Size-Reducer also enables you to use standard 1¼" diameter accessories which you may already own. Here the 5" nozzle, 9" oval nozzle and round brush are useful cleaning aids. All accessories are made of durable plastic and are low in cost.

SWITCH

To start the vacuum cleaner, push the toggle switch lever, "G" Figure 3, to the "ON" position. To stop the cleaner, push the switch lever to the "OFF" position.




FIG. 3

TO USE AS A BLOWER

If you want to use the machine to blow air, simply connect the hose to the exhaust outlet, "F" Figure 3.



EMPTYING AND CLEANING (Figure 4)

Release spring clamps ("E", Figure 1) on drum and lift motor head from drum. Place it on its side. Empty collected materials from drum.

The efficiency of the vacuum cleaner is completely dependent on the air filter bag; it should be kept clean and handled carefully. The bag "I" is held on the bag stretcher "H" by elastic. Remove bag and clean by brushing dust from its surface; don't strike bag against hard or sharp surface as it may damage the cloth. Don't wash bag as its best filtering qualities are retained by air cleaning only. Inspect bag periodically for signs of abrasion, cuts or tears. Replace bag if damaged with No. U-1470 Bag available from B&D Service Center. Failure to do so may result in damage to the motor.

When replacing bag make sure elastic is securely fitted around bag stretcher. Accessory paper bags (No. U-1469) are available to be placed over cloth bag for quick, convenient replacement. Merely throw away the old paper bag and slip a new, clean one over the cloth bag. When using paper bags, make sure that bag is not clogged and is changed regularly. When reassembling motor and tank, make sure that lid is properly seated and that clamps are closed securely.




FIG. 4

LIFE-TIME LUBRICATION

No periodic lubrication is required as your Vacuum Cleaner is equipped with lubricant-sealed ball bearings. The lubricant will last for the life of the bearing.



ACCESSORIES

CAT. NO.	ITEM	USE
U-1461	Rectangular Nozzle w/brush, 2½" diam.	For bulk pick-up of larger items such as leaves.
U-1462	6 ft. plastic hose with coupling, 2½" diam. (Std. equip. with cleaner)	Connect cleaner to 2½" diam. attach.
* U-1463-2	Two 20" Nozzle Extension Tubes, 2½" diam.	Use singly, or joined together to attach to floor tools.
* ☆ U-1464	14" Floor Nozzle with brush, 2½" diam.	Thoroughly cleans floors, walls.
U-1465	Small Round Nozzle, 2½" diam.	With 2½" hose on exhaust outlet, nozzle provides high velocity air flow.
† U-1468	2½" to 1¼" diam. Conversion Size Reducer (Std. Equip.)	Permits use of 1¼" accessories on 2½" hose.
U-1469	Paper Filter Bags, pkg. of 5	Fits over U-1470 bag for quick replacement.
U-1470	Cloth Filter Bag (std. equip. with cleaner)	Filters air passing through motor.
† U-1473	Round Brush, 1¼" diam.	Ideal for cleaning bins, shelves, car floors, other small areas.
* ☆ U-1481	Round Nozzle with brush, 2½" diam.	Perfect for dirt and shavings around irregular surfaces
* † U-1474	5" Nozzle, 1¼" diam. (Standard Equipment)	Perfect for upholstery in cars.
† U-1475	Crevice Tool, 1¼" diam.	Cleans crevices in car and cushions.
* ☆ U-1480	Crevice Tool, 2½" diam. (Standard Equipment)	For use with 2½" diam. hose for cleaning crevices in car and cushions.
† U-1476-2	Two 20" Extension Tubes, 1¼" diam.	Use singly, or joined together to attach to floor tools.
‡ U-1477	9" Oval Nozzle and Brush, 1¼" diam.	Cleans floor, bins, shelves, etc.
‡ U-1478	6 ft. Extension Plastic Hose w/ends, 1¼" diam.	Use with 1¼" diam. accessories.
76-671	Dolly (Std. Equip.)	Adds easy mobility to Cleaner.
* No. U-1482	2½" Diameter ASSORTMENT. Includes above items marked "‡", at a savings.	
* No. 76-685	2½" Diameter ASSORTMENT. Includes above items marked "‡", at a savings.	
* No. U-1483	1¼" Diameter ASSORTMENT. Includes above items marked "†", at a savings.	